

OPEN FIRST!!

Parts list for Master set # 4.18106



1131 VIA CALLEJON, SAN CLEMENTE, CA 92673

© 2007 Energy Suspension. All rights reserved.
May not be reproduced, in any form, or by any means,
without the written consent of Energy Suspension.

Parts list:

Energy Suspension recommends that you **read over all the installation instructions** and check all P/N's and quantities in the parts list **before you start**. Call customer service at 949-361-3935 if the parts in your kit do not match this parts list.

Front radius/strut arm bushing set:

- 4 - 7049 bushings
- 1 - 17230 installation instructions

Front 2 degree "C"-bushing set:

- 4 - 7014 bushings
- 1 - 17231 installation instructions

Front track arm bushing set:

- 2 - 2501 bushings
- 1 - 15.10.18.39 (1.00" O.D. x 3/4" I.D. x 1.750" sleeve)
- 2 - 2502 bushings
- 1 - 15.10.05.39 (3/4" O.D. x 9/16" I.D. x 1.750" sleeve)
- 1 - 17039 installation instructions

Rear leaf spring and shackle bushing set:

- 4 - 2049 main eye spring bushings
- 2 - 15.10.48.39 (7/8" O.D. x 5/8" I.D. x 3.500" sleeve)
- 8 - 2050 rear leaf and frame shackle bushings
- 4 - 15.10.09.39 (3/4" O.D. x 9/16" I.D. x 3.500" sleeve)
- 1 - 17040 installation instructions

Body mount set:

- 2 - 4161 bushings (position #1, top)
- 2 - 4162 bushings (position #1, bottom)
- 2 - 4155 bushings (position #2, top)
- 2 - 4160 bushings (position #2, bottom)
- 2 - 4159 bushings (position #3, top)
- 2 - 4156 bushings (position #3, bottom)
- 2 - 15.03.05.39 (2" O.D. x 1/2" I.D. washer)
- 1 - 17026 installation instructions

Tie-rod boot sets:

- 4 - 13001 tie-rod boot set

Grease:

- 2 - 9.11101 grease tub

It is recommended that if you are unfamiliar with this type of work that you refer to a qualified service center specializing in this type of work. It is also recommended that if you choose to do this work yourself that a factory service manual be obtained for the proper procedures pertaining to removal, replacement and proper torque specifications for your vehicle. This instruction set is intended as a guideline for the safe installation of Energy Suspension's polyurethane bushings, once you have removed the factory components from your vehicle.

Additional parts available for your vehicle:

Shock boots

Fits most aftermarket shocks (2 per set)
set # 9.8130

Swaybar and endlink bushings

Please refer to our newest catalog for more information. Please ask to see our catalog at your place of purchase.

Please refer to our newest catalog for more information on custom applications including bump stops, shock bushings, universal mounts, tie rod boots, ball joint boots, transmission mounts, Formula 5 Prelube etc. Please ask to see our catalog at your place of purchase.

17201

16/APR/07 BRH