

OPEN FIRST!!

Parts list for Master set # 5.18105

Parts list:

Energy Suspension recommends that you **read over all the installation instructions** and check all P/N's and quantities in the parts list **before you start**. Call customer service at 949-361-3935 if the parts in your kit do not match this parts list.

Chrysler front control arm bushing set:(Note: lowers must reuse outer metal shells)

- 4 - 15.02.04.39 ("D" shell)
- 4 - 3203 upper control arm bushing
- 4 - 15.10.114.39 (.708"O.D. x .576" I.D. x 1.690" sleeve)
- 4 - 15.03.32.39 embossed washer 1-3/8" O.D.
- 4 - 15.03.33.39 embossed washer 1-1/8" O.D.
- 2 - 3081 lower control arm bushing (reuse outer metal shell)
- 1 - 17019 installation instructions
- 1 - 17043 installation instructions

Front strut rod bushing set:

- 4 - 7011 strut rod bushing
- 2 - 15.10.201.39 (3/4"O.D. x 5/8" I.D. x 1-13/16" sleeve)

Rear spring and shackle bushing set:

- 8 - 2026 shackle bushing
- Note: Main eye bushing use the following parts according to model**

- 2 - 15.10.14.39 (7/8"O.D. x 5/8" I.D. x 3-1/8" main eye sleeve)

For 426 and 440 models

- 4 - 2025 main eye bushing

Other than 426 and 440 models

- 4 - 2024 main eye bushing
- 1 - 17040 installation instructions

Lower control arm bump stop set:

- 2 - 6032 bump stop
- 2 - 15.07.01.40 (3/8"-16 nut)

Tie-rod boot cover set:

- 4 - 13001 tie-rod boot

Please refer to our newest catalog for more information on custom applications including bump stops, shock bushings, universal mounts, tie rod boots, ball joint boots, transmission mounts, Formula 5 Prelube etc. Please ask to see our catalog at your place of purchase.



1131 VIA CALLEJON, SAN CLEMENTE, CA 92673

© 2007 Energy Suspension. All rights reserved.
May not be reproduced, in any form, or by any means,
without the written consent of Energy Suspension.

It is recommended that if you are unfamiliar with this type of work that you refer to a qualified service center specializing in this type of work. It is also recommended that if you choose to do this work yourself that a factory service manual be obtained for the proper procedures pertaining to removal, replacement and proper torque specifications for your vehicle. This instruction set is intended as a guideline for the safe installation of Energy Suspension's polyurethane bushings, once you have removed the factory components from your vehicle.

Parts list continued:

Front endlink bushing set:

- 8 - 4806 endlink grommet
- 8 - 15.03.01.39 (cupped washer)
- 2 - 15.07.01.40 (3/8"-16 nut)

For 1965-69 B-body vehicles

- 2 - 15.10.23.39 (9/16"O.D. x 3/8" I.D. x 2.90" sleeve)
- 2 - 15.05.04.39 (3/8"-16 x 7" bolt)

For 1970-72 E-body vehicles

- 2 - 15.10.22.39 (9/16"O.D. x 3/8" I.D. x 1.650" sleeve)
- 2 - 15.05.02.39 (3/8"-16 x 5-1/2" bolt)

Grease:

- 1 - 9-11101 grease tub
- 1 - 9-11102 grease packet

Additional parts available for your vehicle:

Transmission mount

- | | |
|-------------------------------|-------------|
| 1970-74 Challenger, Barracuda | set: 5.1101 |
| 1969-70 Super Bee, Charger, | set: 5.1101 |
| Coronet (318, 400, 440) | |
| 1971-76 Charger, Coronet | set: 5.1101 |

SWAY BAR FRAME BUSHING

1970-72 B-body, 70-74 E-body

Diameter		Set #
7/8"	----	5.5113 (reuse O.E. brackets)
15/16"	----	5.5115 (reuse O.E. brackets)
1965-69 B-body		
7/8"	----	5.5134 Greaseable bushings & adapters
		5.5128 O.E. style *
15/16"	----	5.5135 Greaseable bushings & adapters
		5.5129 O.E. style *

* Non-greaseable type. Reuses original brackets, adapters not included.