



advanced FLOW engineering™
P.O. Box 1719
Corona, CA 92879
Support: 951-493-7100
www.aFepower.com

Intake kit Installation Instructions: 05-10 Ford Mustang GT V8-4.6L

Kit P/N: 51/54-10293
Make: Ford
Magnum FORCE Stage-2 Air Intake
Model: **Year:** **Engine:**
Mustang GT '05-'10 V8-4.6L
NOTE:Excluding Mustang GT 2005 LEV II LEV
Engine Test Group 5FMXV04.6VEM, Mustang
GT 2007 LEV II ULEV Engine Test Group
7FMXV04.6VBB, Mustang GT 2007 LEV II LEV
Engine Test Group 7FMXV05.4VEK, Mustang GT
2008 LEV II ULEV
Engine Test Group 8FMXV04.6VBB

2009 Mustang GT LEV II ULEV Engine Test Group
9FMXV04.6VBB, Mustang GT 2009 LEV II LEV
9FMXV05.4VEK, Mustang GT 2010 ARB LEV2 ULEV
AFMXV04.6VDM
Tools Required:
10mm socket or wrench
5/16" nut driver
Phillips screwdriver
Ratchet w/ extention
T-20 torx bit (included)

Parts list:
1 Air filter (P/N 24-90025 or Pro Dry S™ 21-90025)
1 Housing, wrinkle black
1 Tube
1 Coupling, straight 4-1/2" x 2-1/2"
2 Clamp, #072
2 Screw, hex M6 x 1 x 25
2 Washers, wavy M6
2 Nut, M6
2 Washer, flat
1 Gasket, MAF sensor
2 Spacer, nylon 1/2" x 1/4" x 1/8"
2 Screw, phillips #8-32 x 5/16"



Complete Kit w/ Parts

Step 1



Complete Stock Intake.

Step 2



With 5/16" nut driver loosen clamp at throttle body. Disconnect and remove OE crank case line.

Step 3



Loosen the clamp at air box side and remove OE intake tube.

Step 4



Disconnect MAF sensor harness.

Step 5



With 10mm socket or wrench loosen the 2 screws holding in OE air box. Lift up and remove OE air box out of vehicle.

Step 6



With OE screws removed from step 5, install new aFe housing to vehicle. Tighten using 10mm socket or wrench.

Step 7



With T-20 torx bit remove MAF sensor and (with gasket, nylon spacers and screws provided) install into new tube. Make sure gasket and nylon spacers are between sensor and tube.

Step 8



Remove factory crank case line from engine.

Step 9



Install coupler with clamps to tube. Install tube to outside of housing and position coupler on to throttle body.

Step 10



Install screws/nuts and washer provided to mount tube to housing. Tighten using 10mm socket or wrench.

Step 11



Tighten clamps with 5/16" nut driver.

Step 12



Install new 3/8" provided to valve cover side and new tube side.

Step 13



Reconnect MAF sensor harness.

Step 14



Install air filter and tighten using 5/16" nut driver.

Step 15



Your installation is now complete. Please check all bolts and clamps periodically. Re-tighten if necessary. Thank you for choosing aFe! Place enclosed CARB EO sticker on a clean/smooth surface on or near the device. EO identification label is required in passing the smog check inspection.

Note: Filter Cleaning and Re-oiling: When cleaning your aFe filter, be sure to use only aFe's "Restore Kit" (aFe P/N: 90-50001 blue oil aerosol, or aFe P/N: 90-50501 blue squeeze bottle oil)
Filter Replacement: Magnum FLOW PN: 24-90025 (black w/blue media) or Pro Dry S™ P/N 21-90025 (black w/white media) Pro Dry S™ cleaning: see cleaning instruction sheet 06-00074