

OPEN FIRST!!

Parts list for Master set # 5.18106 95-99 Neon



1131 VIA CALLEJON, SAN CLEMENTE, CA 92673

© 2009 Energy Suspension. All rights reserved.
May not be reproduced, in any form, or by any means,
without the written consent of Energy Suspension.

Parts list:

Energy Suspension recommends that you **read over all the installation instructions** and check all P/N's and quantities in the parts list **before you start**. Call customer service at 949-361-3935 if the parts in your kit do not match this parts list.

Front end control arm bushing set: 5.3116

- 2 - 2263 control arm bushings frt. pos. frt. side
- 2 - 3279 control arm bushings frt. pos. rr. side
- 2 - 15.10.296.39 (.813" x .562" x 2.435" sleeve)
- 2 - 3277 control arm bushings rear pos. (vert.)
- 2 - 15.10.83.39 (.875" x .562" x 2.030" sleeve)
- 1 - 17135 installation instructions

Rear end control arm bushing set: 5.3117

- 12 - 2261 bushings (spindle end)
- 4 - 2260 bushings (body end)
- 6 - 15.10.297.39 (.688" x .480" x 1.452" sleeve)
- 8 - 15.03.57.39 (1-1/4" O.D. X 1/2" I.D. Washer)
- 1 - 17136 installation instructions

Rear strut rod set (reuse all original hardware): 5.7110

- 8 - 7094 strut rod bushings

Front Swaybar bushing set: 5.5120

- 2 - 5318 (22mm) swaybar pivot bushings

Front Swaybar bushing set: 5.5144

- 2 - 5497 (20mm) swaybar pivot bushings

Front endlink set: 5.8101

- 2 - 15.10.56.39 (.562" x .375" x 1.000" sleeve)
- 8 - 8072 endlink bushings
- 8 - 15.03.03.40s cupped washer
- 2 - 15.05.28.39 (3/8-16 x 3-3/4" bolt)
- 2 - 15.07.01.40 (3/8-16 nylock nut)
- 1 - 17039 installation instructions

Rear Swaybar bushing set: 5.5121

- 2 - 5319 (16mm) swaybar pivot bushings

Rear endlink set: 5.8102

- 4 - 8005 end link bushings
- 4 - 15.10.250.39 (.625" x 10mm x 1.210" sleeve)
- 1 - 17039 installation instructions

It is recommended that if you are unfamiliar with this type of work that you refer to a qualified service center specializing in this type of work. It is also recommended that if you choose to do this work yourself that a factory service manual be obtained for the proper procedures pertaining to removal, replacement and proper torque specifications for your vehicle. This instruction set is intended as a guideline for the safe installation of Energy Suspension's polyurethane bushings, once you have removed the factory components from your vehicle.

Parts list continued:

Tie rod boot set: 9.13103

- 2 - 13003 tie rod boots

Grease:

- 2 - 9.11113 grease tubs

Please refer to our newest catalog for more information on custom applications including bump stops, shock bushings, universal mounts, tie rod boots, ball joint boots, transmission mounts, Formula 5 Prelube etc. Please ask to see our catalog at your place of purchase.