

OPEN FIRST!!

Parts list for Master set # 16.18104 1990-93 Acura Integra

Parts list:

Energy Suspension recommends that you **read over all the installation instructions** and check all P/N's and quantities in the parts list **before you start**. Call customer service at 949-361-3935 if the parts in your kit do not match this parts list.

Transmission shifter stabilizer bushing set: 16.1101

- 1 - 1033 (mounts near shifter)
- 1 - 1032 (mounts at the transmission)
- 1 - 17161 installation instructions

Front end control arm bushing set: 16.3108

- 4 - 2271 lower control arm pivot bushing
- 2 - 15.10.24339 (.750"O.D. x .406" I.D. x 2.038" sleeve)
- 2 - 3281 lower control arm pivot bushing
- 4 - 3291 upper control arm pivot bushing
- 4 - 15.10.299.39 (.750"O.D. x .406" I.D. x 1.486" sleeve)
- 1 - 17156 installation instructions

Rear end control arm bushing set: 16.3109

- 8 - 2301 lower control arm pivot bushing
- 4 - 3288 lower control arm pivot bushing
- 4 - 15.10.279.39 (.750"O.D. x .406" I.D. x 1.960" sleeve)
- 1 - 17140 installation instructions

Front strut rod set: 16.7104 (reuse all original hardware)

- 4 - 7096 strut rod bushing
- 2 - 15.10.255.39 (.688" x .480" I.D. x 2.340" sleeve)

Front shock bushing set: 16.8102 (press out bushing and shell)

- 4 - 2272 lower control arm shock mount
- 4 - 8096 upper shock mount (use O.E. sleeve)
- 2 - 15.10.245.39 (.750"O.D. x .480" I.D. x 1.960" sleeve)
- 1 - 17162 installation instruction

Rear shock bushing set: 16.8103 (press out bushing and shell)

- 4 - 2270 lower control arm shock mount
- 4 - 8096 upper shock mount (use O.E. sleeve)
- 2 - 15.10.279.39 (.750"O.D. x .406" I.D. x 1.960" sleeve)
- 1 - 17163 installation instruction



1131 VIA CALLEJON, SAN CLEMENTE, CA 92673

© 2010 Energy Suspension. All rights reserved.
May not be reproduced, in any form, or by any means,
without the written consent of Energy Suspension.

It is recommended that if you are unfamiliar with this type of work that you refer to a qualified service center specializing in this type of work. It is also recommended that if you choose to do this work yourself that a factory service manual be obtained for the proper procedures pertaining to removal, replacement and proper torque specifications for your vehicle. This instruction set is intended as a guideline for the safe installation of Energy Suspension's polyurethane bushings, once you have removed the factory components from your vehicle.

Parts list continued:

Front endlink set: 16.8104

- 8 - 8072 endlink bushing
- 2 - 15.10.226.39 (.562" O.D. x .375" I.D. x .400" sleeve)
- 8 - 15.03.03.40 cupped washer
- 2 - 15.05.28.39 (3/8"-16 x 3-3/4" bolt)
- 2 - 15.07.01.40 (3/8"-16 nylock nut)
- 1 - 17039 installation instructions
- 1 - installation instructions

Rack and pinion bushing set: 16.10103

- 4 - 10022 drivers side (all models)
- 1 - 10025 passenger side (power steering only, bushing not available for other models)
- 1 - 17153 installation instructions

Front balljoint boot set: 16.13101

- 2 - 13001 (lower balljoint)
- 2 - 13003 (upper balljoint)

Tie rod boot set: 9.13103

- 2 - 13003 tie rod boots

Additional parts available for your vehicle:

Rear Trailing Arm bushing set: 16.7107

Front anti-swaybar bushing set (does not include endlinks):

Bar Dia.	Set #
23mm	16-5113
22mm	16-5118

Rear anti-swaybar bushing set (does not include endlinks):

Bar Dia.	Set #
16mm	16-5114
15mm	16-5112

17160

17/MAR/10 BRH

Please refer to our newest catalog for more information on custom applications including bump stops, shock bushings, universal mounts, tie rod boots, ball joint boots, transmission mounts, Formula 5 Prelube etc. Please ask to see our catalog at your place of purchase.