

OPEN FIRST!!

Parts list for Master set # 4.18110



1131 VIA CALLEJON, SAN CLEMENTE, CA 92673

© 2007 Energy Suspension. All rights reserved.
May not be reproduced, in any form, or by any means,
without the written consent of Energy Suspension.

Parts list:

Energy Suspension recommends that you **read over all the installation instructions** and check all P/N's and quantities in the parts list **before you start**. Call customer service at 949-361-3935 if the parts in your kit do not match this parts list.

Transmission mount:

- 1 - 1044 mount
- 1 - 15.08.24.39 backing plate.
- 2 - 15.03.48.39 (7/16" lockwasher)
- 4 - 15.03.42.39 (7/16" flat washer)
- 2 - 15.05.30.39 (7/16"-14 x 1" bolt)
- 1 - 17227 installation instructions

Transmission crossmember mount to frame bushing set:

- 4 - 4087 bushing
- 2 - 15.10132.39 (.750"O.D. x .437" I.D. x 4.500 sleeve)

Front end control arm bushing set:

- 2 - 3236 lower control arm pivot bushing, rear position
- 2 - "U" shell (use with 3236 bushing)
- 2 - 15.10.33.39 (.875"O.D. x .625" I.D. x 3.187 sleeve)
- 2 - 3237 lower control arm pivot bushing, front position
- 2 - "O" shell (use with 3237 bushing)
- 2 - 15.10.34.39 (.875"O.D. x .625" I.D. x 3.00 sleeve)
- 1 - 17110 installation instructions

Rear end control arm bushing set:

- 2 - 3027 lower control arm pivot bushing, axle end
- 2 - 3076 lower control arm pivot bushing body end (oval shape)
- 4 - 15.10.171.39 (.750"O.D. x .480" I.D. x 2.900 sleeve)
- 2 - 3028 upper control arm pivot bushing, body end
- 2 - 3029 upper control arm pivot bushing axle end
- 4 - 15.10.170.39 (.750"O.D. x .480" I.D. x 2.400 sleeve)
- 2 - 3098 thrust washer use with 3029 bushing
- 2 - 3099 thrust washer use with 3028 bushing
- 2 - 3101 thrust washer use with 3027 bushing
- 2 - 3109 thrust washer use with 3076 bushing
- 1 - 17041 installation instructions
- use 17019 installation instructions

Front spring isolator set:

- 2 - 6070 upper
- 2 - 6071 lower

Rear spring isolator set:

- 2 - 6053 upper
- 2 - 6054 lower

Tie-rod boot set: 2 - 13001 tie-rod boot

Grease: 3 - 9.11101 grease tub

It is recommended that if you are unfamiliar with this type of work that you refer to a qualified service center specializing in this type of work. It is also recommended that if you choose to do this work yourself that a factory service manual be obtained for the proper procedures pertaining to removal, replacement and proper torque specifications for your vehicle. This instruction set is intended as a guideline for the safe installation of Energy Suspension's polyurethane bushings, once you have removed the factory components from your vehicle.

Parts list continued:

Front McPherson strut tower bushing set:

- 2 - 2215 bottom bushing
- 2 - 2214 top bushing
- 2 - 15.10.51.39 (.875"O.D. x .625" I.D. x 2.125 sleeve)
- 1 - 17275 installation instructions

Front Swaybar endlink set :

- 8 - 4806 endlink grommets
- 2 - 15.10.47.39 (.563"O.D. x .375" I.D. X 4.500" sleeve)
- 8 - 15.03.01.39 (cupped washer)
- 2 - 15.05.06.39 (3/8"-16 x 8.5" bolt)
- 2 - 15.07.01.40 (3/8"-16 nut)

Rack and pinion bushing set for stock height to 1-1/4" lowered vehicles):

- 4 - 10003 bushing
- 1 - 17094 installation instructions

Offset rack and pinion bushing set for vehicles lowered more than 1-1/4": (these offset rack bushings help correct the bump steer caused by lowering the vehicle):

- 4 - 10020 bushing
- use 17094 installation instructions

Additional parts available for your vehicle: Front anti-swaybar bushing set (does not include endlinks):

1979-96 Front anti-swaybar bushing set:

Bar Dia.	Set #
7/8"	4-5113
15/16"	4-5112
1"	4-5111
1-1/16"	4-5110
1-1/8"	4-5109
30mm	4-5135
1-1/4"	4-5108
1-5/16"	4-5101
1-3/8"	4-5136

Please refer to our newest catalog for more information on custom applications including bump stops, shock bushings, universal mounts, tie rod boots, ball joint boots, transmission mounts, Formula 5 Prelube etc. Please ask to see our catalog at your place of purchase.