

OPEN FIRST!!

Parts list for Master set # 3-18111

Parts list:

Energy Suspension recommends that you **read over all the installation instructions** and check all P/N's and quantities in the parts list **before you start**. Call customer service at 949-361-3935 if the parts in your kit do not match this parts list.

Transmission mount: 3.1108

- 1 - 1036 mount
- 1 - 15.08.10.39 backing plate
- 2 - 15.03.48.39 (7/16" lockwasher)
- 4 - 15.03.42.39 (7/16" flat washer)
- 2 - 15.05.30.39 (7/16"-14 x 1" bolt)
- 1 - 17112 installation instructions.

Front control arm bushing set: 3.3105

Must reuse all factory hardware

- 2 - 3005 upper control arm bushings(rear position)
- 2 - 15.10.12.39 (.813" O.D. x .681" I.D. x 1.80" sleeve)
- 2 - 15.02.06.39 ("F" shells)
- 2 - 3012 upper control arm bushings(front position)
- 2 - 15.10.41.39 (.813" O.D. x .688" I.D. x 2.100" sleeve)
- 2 - 15.02.07.39 ("G" shells)
- 2 - 3009 lower control arm bushings(rear positions)
- 2 - 15.10.55.39 (.750" O.D. x .563" I.D. x 2.400" sleeve)
- 2 - 15.02.03.39 ("C" shells)

For vehicles with(1-5/8" O.D. shells)

- 2 - 3010 lower control arm bushings (front position)
- 2 - 15.10.55.39 (.750" O.D. x .563" I.D. x 2.400" sleeve)
- 2 - 15.02.02.39 ("B" shells) (1-3/8" O.D.)
- 1 - 17019 installation instructions

For vehicles with(1-3/8" O.D. shells)

- use the following bushings, shells and sleeves in place of the 3010 bushing, "B" shells and
- The 15.10.55.39 sleeves
- 2 - 15.02.01.39 ("A" shells) (1-5/8" O.D.)
- 2 - 3006 lower control arm bushings front position
- 2 - 15.10.10.39 (.750"O.D. x .500" I.D. x 2.400" sleeve)

Rear control arm bushing set: 3.3132

- 8 - 3021 control arm bushings.
- 8 - 15.10.1039 (3/4"O.D. x 1/2" I.D. x 2.425" sleeve)
- 8 - 15.02.09.39 "I" shells.
- 6 - 3087 thrust washers.
- 6 - 3088 thrust washers.
- 2 - 3089 thrust washers.
- 1 - 9.11101 grease tubes.
- 1 - 17041 installation instructions.
- 1 - 17019 installation instructions.



1131 VIA CALLEJON, SAN CLEMENTE, CA 92673

© 2005 Energy Suspension. All rights reserved.
May not be reproduced, in any form, or by any means,
without the written consent of Energy Suspension.

It is recommended that if you are unfamiliar with this type of work that you refer to a qualified service center specializing in this type of work. It is also recommended that if you choose to do this work yourself that a factory service manual be obtained for the proper procedures pertaining to removal, replacement and proper torque specifications for your vehicle. This instruction set is intended as a guideline for the safe installation of Energy Suspension's polyurethane bushings, once you have removed the factory components from your vehicle.

Parts list continued:

Front endlink set : 9.8118

- 8 - 4806 endlink grommets
- 8 - 15.03.01.39 (cupped washer)
- 2 - 15.05.04.39 (3/8"-16 x 7" bolt)
- 2 - 15.07.01.40 (3/8"-16 nut)
- 2 - 15.10.21.39 (9/16"O.D. x 3/8" I.D. x 2.6" sleeve)

Tie-rod dust boot set: 9.13101 (2 sets)

- 4 - 13001 tie-rod dust boots.

Ball-joint dust boot set: 9.13125

- 2 - 13009 ball-joint boots.

Additional parts available for your vehicle:

UNIVERSAL/MULTI. APPLICATION SWAY BAR BUSHINGS

Greaseable		Non-greaseable	
Set #	Diameter	Set #	
9.5151	7/16"	9.5101	
9.5152	1/2"	9.5102	
9.5153	9/16"	9.5103	
9.5154	5/8" (16mm)	9.5104	
9.5155	11/16"	9.5105	
9.5156	3/4" (19mm)	9.5106	
9.5157	13/16"	9.5107	
9.5158	7/8" (22mm)	9.5108	
9.5159	23mm	9.5115	
9.5160	15/16" (24mm)	9.5109	
9.5161	1"	9.5110	
9.5162	1 1/16"	9.5111	
9.5163	28mm	9.5130	
9.5164	1 1/8"	9.5112	
9.5165	1 1/4"	9.5113	
9.5166	32mm	9.5116	
9.5167	1 5/16"	9.5114	
9.5168	1 3/8"	9.5136	

Please refer to our newest catalog for more information on custom applications including bump stops, shock bushings, universal mounts, tie rod boots, ball joint boots, transmission mounts, Formula 5 Prelube etc. Please ask to see our catalog at your place of purchase.

17216

6/AUG/09 BRH